


H76H-10C H76W-10P H76W-10R H76H-16C H76W-16P H76W-16R  
H76H-25 H76W-25P H76W-25R H76H-40 H76Y-40P H76



<b>seleccionar Consulta</b>		<b>DN</b>	<b>l</b>	<b>D</b>	<b>l</b>	<b>D</b>	<b>l</b>	<b>D</b>	<b>lD</b>
50	60	109	60	109	60	109	60	109	
65	67	129	67	129	67	129	67	129	
80	73	144	73	144	73	144	73	144	
100	73	164	73	170	73	170	73	170	
125	83	194	83	198	83	198	83	198	
150	98	220	98	228	98	228	98	228	
200	127	275	127	288	127	288	127	293	
250	146	330	146	343	146	343	146	355	
300	181	380	181	403	181	403	181	420	
350	184	440	184	460	184	460	222	480	
400	198	493	198	520	198	520	232	549	
450	203	543	203						
500	219	598	219						
600	222	698	222						